



BUNN ULTRA 2 OPERATING INSTRUCTIONS

- 1) **CHECK HOPPER SEALS:** Before filling hoppers, pour 1 gallon of water in each hopper to make sure that the seals in back have not been jarred loose. If water leaks from rear, drain remaining water and gently push front of hopper down and inward until button at lower left front of hopper engages. Repeat procedure. If you cannot obtain tight seal, carefully remove hopper and coat the seal (white, located behind auger) with thin layer of Vaseline, then reseal.
- 2) **STARTING MACHINE:** If using both hoppers, start the machine by pushing the left and right side auger ON/OFF switches until **AUGER ON** appears. Next, turn on the left and right side control switches (OFF, ICE or CHILL) until **ICE** appears.
- 3) **ADD COLD WATER FIRST:** Then pour the desired flavors in from the top of the machine. Follow the mixing instructions. Depending on water and room temperature, allow about 60 to 120 minutes before serving. Cold water will speed up this process.
- 4) **USING BAR MIXES:** After pouring water and mixes into the machine, wait until the mixture becomes slushy to add alcohol (alcohol takes longer to freeze, so adding alcohol later will speed up the freezing process). Pour only half of the desired liquor to start with - then taste test and continue to add more liquor until you reach the desired strength.
- 5) **ADDING MORE PRODUCT:** When mixing blades become exposed, repeat mixing instructions. It will take about 30 to 45 minutes before you can start serving again. When adding product, slide the top of the hopper backwards.
- 6) **WHEN FINISHED USING THE MACHINE:** Turn off the machine. Empty the hoppers. Add one gallon of warm water to each hopper and drain. Do this twice. This helps rinse out the machine. Do not do any other cleaning.

BUNN ULTRA 2 WARNINGS & OPERATING TIPS

- 1) **KEEP IN COOL AREA:** Machine will not work well outside or in high temperatures. If operating outside, make sure to place machine in a shaded area.
- 2) **DO NOT USE EXTENSION CORD IF POSSIBLE:** Using the wrong extension cord could cause mixing delays and/or loss of power. A thin wire (non-industrial type) cord could starve the 120 volt compressor of needed electrical surge for proper operation. If extension cords are used, select only heavy duty cords.
- 3) **DO NOT ADD ICE TO THIS MACHINE:** This unit makes its own ice. The Bunn Ultra 2 has a reversing auger that gives you better mixing faster - this improves freeze time so that you have frozen drinks sooner.
- 4) **USE ONLY PRODUCTS RECOMMENDED BY AV PARTY RENTALS:** AV Party Rentals is not responsible for providing mixing instructions for products not supplied by AV Party Rentals.