



# OPTIONS AND ACCESSORIES

**ADD  
VALUE,  
CONVENIENCE  
AND  
COMFORT**



**One Tough Animal**

## Please Note:

Many of the options and accessories found on these pages are available for some models of Bobcat equipment only. Some options are factory-installed only. Some options are standard on certain machines.

*Please consult your Bobcat dealer for details!*

## Advanced Control System

The Bobcat Advanced Control System (ACS) lets loader operators use a dash-mounted switch to instantly select between advanced hand control or new advanced foot control of lift and tilt functions. ACS is designed to accommodate all loader operators. Whether operators prefer to control lift and tilt functions by hand or by foot, ACS gives them an instant choice at the flip of a switch. Here's the opportunity for fleet owners to give operators the machine controls they prefer.




## Attachment Control Kit

Get added convenience with in-cab electric control for Bobcat attachments, such as the angle broom, grader, soil conditioner, stump grinder and planer with hydraulic skid-depth control.




## Back-Up Alarm

A beeper sounds when the loader is backing up. Available for customers requiring back-up alarms in applications involving low visibility.



## Catalytic Purifier

Available for diesel-powered loaders and excavators. Purifier reduces amount of carbon monoxide and other emissions. Particularly useful for indoor applications.



## Climate-Controlled Cab

High-visibility front door — with 49% more glass — includes wiper and washer. The cab enclosure with top, rear and sidewindows, will completely seal the cab for efficient use of heater or the air conditioning option.



## Counterweight Kits

Counterweight kits are available for 753, 763, 773, 863, 873, 883 and 963 models to increase rated operating capacity. A front axle counterweight kit (shown) to improve performance in certain applications or with certain attachments is also available for these models.



## Decal Kits

Replace missing or torn safety decals and other machine signs.



## Deluxe Operator's Cab

Enhances operator comfort on Bobcat loaders with additional interior foam padding, top and rear windows, wire harness, dome light and electrical power port.




## Excavator Enclosed Operator's Cab

An optional cab is equipped with heating, ventilation and air conditioning systems. The super-efficient cab heater lets you work in comfort even during the coldest winter months. In hot weather, Bobcat air conditioning is capable of a significant temperature differential to keep you on the job all day without breaking a sweat.



## Excavator Steel Tracks

Standard rubber tracks can be replaced with steel tracks on some Bobcat excavator models. (Replacement may require a separate adapter kit or additional parts.)



## Horn

Allows operator to produce an audible signal.




## Hose Retainer Kit (D Ring)



Secures attachment hydraulic lines. It's installed on the loader and can be used with most attachments.

## Hydraulic Bucket Positioning Kit

Provides hydraulic bucket (or other attachment) positioning. Helps operator keep same tilt of load during lift.



## Instrument Panels

State-of-the-art instrument panels provide dozens of operational features, diagnostics and monitoring. Optional loader deluxe instrument panel includes keyless start security system, feature lockouts, digital time and job clocks, multi-language display, even a "help" menu.



## Lift Arm Support

Used when the loader's lift arms are raised for service work. The support mechanically prevents the raised lift arms from lowering. Lift arm support is now standard on all loader models.



## Lift Kits


Single-point and four-point lift kits are available for many Bobcat loaders. After installation, loaders may be lifted into remote areas such as barge holds.

## Locking Fuel Cap

Provides added security from fuel theft or vandalism.



## Power Bob-Tach™



Change standard attachments at the flip of a switch — without leaving the cab! Activating the Power Bob-Tach switch on the dash panel engages the Bob-Tach wedges into the attachment. Hydraulic-driven attachments still require you to shut off the loader and exit the cab to connect and disconnect the hydraulics.

## Protection Plus Extended Warranty



Extend the standard 12-month warranty of your Bobcat loader or excavator to 24 or 36 months for added protection.

## Rear Auxiliary Hydraulics

Available on certain models, this option provides hydraulic flow to the rear of the loader to operate rear stabilizers.



## Replacement Loader Operator's Cab & Excavator Canopy

Includes decals, instrument panel, seat bar or foam padding. Available for all loader and excavator models. Meets SAE ROPS and FOPS (Level I) requirements. Level II FOPS Top Kit is available for loaders. Does not include seat.



## Seat Bar Kits

Seat bar kits are available for all Bobcat loaders. The padded seat bar is a secondary restraint device, and also serves as a comfortable armrest. Large operator seat bar kit provides additional room for the operator.



## Sound Cab

Additional sound-deadening insulation reduces noise at operator's ear. Available as a factory-installed option on all loader models.

## Special Applications Kit

Restricts objects and material from entering cab openings. Consists of a Lexan front door and top and rear windows. Special Applications Kit must be used with Bob-Tach-mounted hydraulic breaker.

## Suspension Seat

The optional, fully-adjustable suspension seat allows comfortable all-day operation.



## Tires

Ask your Bobcat dealer for current tire options for your Bobcat skid-steer loader.

## Training Resources

Make sure operators are trained thoroughly. Individual replacement operation and maintenance manuals, operator's handbooks and EMI and CIMA safety manuals are available for Bobcat loaders and excavators. Individual video tapes (Spanish versions available) and comprehensive training course kits for Bobcat skid-steer loaders, excavators, backhoe attachments, planer attachments and service safety are also available.



## Water Kit - Quick-Tach

Used with attachments such as the planer, vibratory roller, angle broom or sweeper, the Water Kit helps reduce dust. The kit's 14-gallon tanks are quickly mounted to the loader's uprights. Water is supplied to the nozzles (a separate nozzle kit for each attachment is required) by an electric pump. The kit contains tanks, pump, plumbing, wiring harness and mounting hardware.



## And More:

AM/FM Radio Kit • Block/Tank Heaters Enclosed Alternator • Excavator Cab Canopy Light Kit • Excavator FOPS Kit Fire Extinguishers • 4-Way Flasher Kit High Flow • Rental Protection Kit Rotating Beacon • and many, many more.

## See Your Bobcat Dealer For Full Details!

Bobcat Company complies with the requirements of ISO 9001 as registered with BSI.

